

21+



STARRY 3.0



ANLEITUNG

Achtung!

Bitte sorgen Sie dafür, dass das Gerät nicht für längere Zeit einen niedrigen Ladestand hat, denn wenn der Ladestand unter 2% fällt lässt es sich nicht mehr aufladen.

Laden Sieden Akkumiteinem dafür vorgesehenem Ladegerät von guter Qualität und niemals mit mehr als 5V/1A. Andernfalls kann dies das Gerät beschädigen und zu shveren Verletzungen sowie Bränden führen.



Benutzen Sie KEINE beschädigten Batterien. Bitte benutzen Sie unsere original Batterien oder andere qualitativ hochwertige Batterien von authentischen Marken.

Verwenden Sie immer für Ihr Gerät geeinete Batterien. Tragen Sie es niemals lose mit anderen Metallgegenständen in Ihrer Tasche.



1

Sicherheit

Vielen Dank, dass Sie sich für einen XMAX STARRY 3.0 entschieden haben. Wir hoffen Sie genießen die Qualität und Leistung Ihres XMAX STARRY 3.0.

Um optimale leistung und Sicherheit zu gewährleisten, lesen sie bitte die gesamte Bedienungsanleitung.

Bitte lesen und befolgen Sie die Anweisungen sorgfältig bevor Sie Ihren XMAX STARRY 3.0 benutzen.

Bewahren Sie diese Anleitung zum späteren Nachschlagen an einem sicheren Ort auf.

XMAX STARRY 3.0 ist kein medizinisches Gerät und nicht dazu gedacht Krankheiten oder andere Probleme zu diagnostizieren, heilen, behandeln oder zu verhindern. Falls Sie gesundheitliche Probleme haben konsultieren Sie vor der Anwendung des XMAX STARRY 3.0 Ihren Arzt.

Dieses Produkt darf nicht von Kindern, Frauen, die schwanger sind oder stillen verwendet werden, oder von Personen, die an einer lebensbedrohliche Erkrankung leiden ohne vorher eingen Arzt zu konsultieren. Niemals vor dem Fahren benutzen!

Dieses Gerät ist nch für den Einsatz von illegalen Substanzen bestimmt. Bei derartigem Einsatz können Bußgelder, Strafen und/oder Freiheitsstrafen, je nach dem bei Ihnen geltenden Gesetze, verhängt werden.

DIESES PRODUKT ENTHÄLT KEIN PELANZEN-MATERIAL.

2

XMAX STARRY 3.0 ÜBERBLICK



Mundstück

Heizkammer

18650 Batterie

XMAX STARRY 3.0 INHALT



Stopfwerkzeug

Reinigungsbürste

USB Kabel

Pinzette

18650 Batterie

Tropfenkissen

3

TECHNISCHE EINZELHEITEN

Batterie Kapazität	18650 3.7V 2600 mAh
Spannung	5.0V/1A
Aufladen	Micro USB
Ein/Aus	Ein-/Ausschalter 3 Sekunden drücken
Sicherheitsabschaltung	5 Minuten und 10 Minuten optional
Heizkammer	Keramik mit eingebautem Heizelement
Display	OLED
Temperaturbereich	100°C - 240°C (212°F - 464°F)
Größe	110mm*35mm*24mm

4

GEBRAUCHSANWEISUNG

1. Entfernen Sie die Magnetkappe.



2. Füllen Sie die Kammer mit gemahlene Kräutern.



(Für Konzentrate: setzen Sie die Wackammer in die Keramikammer und füllen sie.)

3. Bringen Sie die Magnetkappe wieder an.



5


4. Halten Sie den Ein-/Ausschalter 3 Sekunden lang gedrückt, um den XMAX STARRY 3.0 anzuschalten. Er heizt sich dann sofort auf. Während des Heizvorgangs blinkt das Zeichen "☕". Warten Sie bis diese Zeichen nicht mehr blinkt. Das Gerät ist jetzt einsatzbereit.




6

5. Drücke Sie "+" um die Temperatur zu erhöhen und "-" um sie zu verringern. Der XMAX STARRY 3.0 stellt sich beim Neustart automatisch wieder auf Ihre letzten Einstellungen ein.

Das Zeichen "☕" leuchtet auf und die Vibration des Geräts zeigt die Einsatzbereitschaft an. Inhalieren Sie durch das Mundstück und genießen Sie bis das Display ausgeht und die Vibration endet.



6. Um zwischen Fahrenheit und Grad Celsius umzustellen, halten Sie gleichzeitig de Ein-/Ausschalter und den "-" Schalter 2 Sekunden lang gedrückt



7. Um den Timer von 5 auf 10 Minuten umzustellen, halten Sie gleichzeitig den Ein-/Ausschalter und den "+" Schalter 2 Sekunden lang gedrückt.



AUFLADEN

1. Um den Akku zu schützen wird empfohlen ihn vor dem ersten Gebrauch mindestens 6 Stunden an der Steckdose laden zu lassen ein externes 18650 Batterie-Ladegerät ist verfügbar, jedoch nicht im Lieferumfang enthalten)

7



2. Während des Aufladens leuchtet das Display auf. Die Batterieanzeige zeigt den Ladefortschritt an. Das Symbol ist voll, wenn das Gerät vollständig aufgeladen ist.




Lassen Sie den XMAX STARRY 3.0 vor dem Verstauen abkühlen. Lagern Sie beides kühl und trockenun daußer Reich weite von Kindern.

8


REINIGUNG UND INSTANDHALTUNG

Um Ihr Gerät Instand zu halten wird empfohlen, die Kammer und das Mundstück nach jedem Gebrauch zu reinigen.

1. Zum Reinigen des Mundstücks wischen Sie das Innere zunächst mit einem Wattestäbchen und dann mit einem feuchten Papierhandtuch ab.



2. Zur Reinigung des Filters entfernen Sie ein Glas mit Isopropylalkohol vor. Entfernen Sie den Filter von der Maenetkappe und legen Sie ihn in das Glas



3. Um die Heizkammer zu Reinigen, feuchten Sie ein Wattestäbchen mit dem Alkohol an. Putzen Sie damit in kreisförmigen Bewegung an. Putzen Sie Innenseite und den Boden der Kammer.



9

4. Entfernen Sie alle Rückstände mit einem Wattestäbchen. Lassen Sie alle Teile vor dem nächsten Gebrauch gut trocknen.

Hinweis

REINIGEN SIE NICHT DAS GANZE GERÄT MIT WASSER ODER TAUCHEN ES DARIN EIN.

FÜLLEN SIE KEINE FLÜSSIGKEITEN ODER ÖL IN DIE KERAMIKKAMMER.

STELLEN SIE SICHER, DASS DER XMAX STARRY 3.0 DURCH SPERREN DEAKTIVIERT IST, SEIT MINDESTENS 30 MINUTEN NICHT BENUTZ WURDE UND VOLLSTÄNDIG ABGEKÜHLT IST.

Warnung

BERÜHREN SIE DAS HEIZELEMENT NICHT SOFORT NACH DEM GEBRAUCH. LASSEN SIE DAS GERÄT ABKÜHLEN.

NICHT IN WASSER ODER ISOPROPYALKOHOL TRÄNKEN ODER EINTAUCHEN.

10

ALTER

XMAX STARRY 3.0 Aufgrund von Gebrauch eines XMAX STARRY 3.0 volljährig sein. Nur für Erwachsene.

GEBRAUCH

Verwenden Sie das Gerät niemals, bevor Sie nicht die Gebrauchsanweisung gelesen haben. Falls irgendwelche Unklarheiten, vor allem im Gebrauch, auftreten sollten, kontaktieren Sie bitte unseren Kundenservice

BESCHÄDIGUNG

Stellen Sie die Verwendung des Produkts sofort ein, wenn der Vaporizer in irgendeiner Weise beschädigt ist, einschließlich, jedoch nicht beschränkt auf: Dellen, überhitzen, und/oder elektronische Fehlfunktionen.

Versuchen Sie nicht das Produkt, durch demontieren von nicht austauschbaren Teile, zu reparieren. Ausgenommen: Mundstück, Heizelement, Stopfwerkzeug oder auswechselbare Batterie. Kontaktieren Sie unseren Kundenservice bei beschädigten Gerät en.

11

Alle Batterien können bei unsachgemäßem Gebrauch oder der falschen Handhabung explodieren oder sich entzünden. Nicht auseinandernehmen, durchbohren, manipulieren, schneiden, zerkleinern, kurzschließen, verbrennen, oder Wasser, Feuer oder hohen Temperaturen über 60°C oder 140°F aussetzen. Verwenden Sie mit diesem Gerät niemals beschädigte oder unsachgemäß verpackte Batterien.

Es liegt in Ihrer Verantwortung, die Gefahren und die richtigen Maßnahmen für den Umgang mit allen Batterien zu verstehen. Nicht in Abfallbehälter entsorgen und die Umwelt nicht verunreinigen. Bitte recyceln oder entsorgen Sie nach den geltenden Sicherheitsvorschriften. (Es wird empfohlen, die Klemme vor der Entsorgung mit einem geeigneten Isolierband abzudecken)

ACHTUNG!

DIESES PRODUKT IST NICHT ZUR NUTZUNG MIT NIKOTIN GEEIGNET.

DAS PRODUKT IST AUSSCHLIEßLICH FÜR DEN GEBRAUCH MIT LEGALEN KRÄUTERN BESTIMMT. DAS PRODUKT ENTHÄLT KEINE PFLANZLICHEN INHALTSSTOFFE.

HALTEN SIE DAS GERÄT VON KINDERN UND HAUSTIEREN FERN.

BESCHRÄNKTE GARANTIE

Das Produkt wird für einen Zeitraum von einem (1) Jahr ab Kauf mit Kaufbeleg oder einem (1) Jahr ab Herstellungsdatum ohne Kaufbeleg gegen Mängel in Fertigung, Verarbeitung und Materialien gewährleistet. Dieses Gerät ist ausschließlich für die Verwendung von legalen Konzentraten ausgelegt. Jede Verwendung des XMAX STARRY 3.0 mit illegalen Substanzen führt zum Erlöschen der Garantie.

12

Die Garantie gilt nicht für Schäden, die durch Unfall, Missbrauch, Fehlbedienung, Naturkatastrophen, Benutzerfehler oder Verwendung außerhalb des in der Anleitung beschriebenen Verwendungszwecks verursacht werden. Die Verwendung außerhalb des bestimmungsgemäßen Gebrauchs, wie in diesem Handbuch beschrieben, beinhaltet auch jede Manipulation des Geräts in irgendeiner Weise, einschließlich, aber nicht beschränkt auf Modifikationen zur Änderung der Funktionalität oder Modifikationen zur Änderung des Aussehens.

Die Garantie gilt auch nicht für kosmetische Schäden, einschließlich, aber nicht beschränkt auf Beulen, Kratzer/ Splitter der Oberfläche und/oder beschädigte Kunststoffteile.

Normaler Produktverschleiß ist nicht von der Garantie abgedeckt. Eine übliche Leistungsabnahme der Batterien ist ebenfalls nicht von der Garantie abgedeckt.

Um einen Garantieanspruch geltend zu machen, wenden Sie sich bitte an den Kundendienst unter support@topgreencig.com. Für die Einlösung der Garantie sind der Originalkaufbeleg, der Authentizitätscode, Bilder oder Videos sowie alle Seriennummern erforderlich.

Nach Ermessen des Herstellers wird die Garanteileistung durch Reparatur des Produkts oder Austausch des Produkts und/oder Teils gegen ein neues oder funktional gleichwertiges Produkt/Teil erbracht.

KUNDENSUPPORT

Für Fragen oder Bedenken bezüglich des Produkts, seiner Verwendung oder Mängel wenden Sie sich bitte an den Kundendienst unter support@topgreencig.com. Wir werden unser Bestes tun, um innerhalb von zwei (2) Werktagen nach Erhalt der schriftlichen Mitteilung eine Antwort zu geben.

www.topgreen-tech.com
© Topgreen Technology 2019



13

14

Caution

- Please do not put this product away or leave it for extended periods of time with low charge because if the battery falls below 2% then it will no longer accept a charge.
- Charge the battery with a good quality & dedicated charger. Never more than 5V/1A. Otherwise, it will cause damage to battery, serious personal injury, fire.



- Do NOT use damaged batteries in all our vaporizers
- Please use our original batteries or high quality batteries from authentic brands instead of clones

- Always use battery suitable for your device. Never carry it loose in your pocket with other metal objects.



15

DISCLAIMER

Thank you for purchasing the XMAX STARRY3.0 aromatherapy diffuser. We hope you enjoy the quality and performance of your XMAX STARRY3.0.

To ensure optimal performance and safety of XMAX STARRY3.0, please read this entire manual instructions.

Please read and follow instructions carefully. Understand them fully before using your STARRY3.0.

We recommend you keep these instructions in a safe place for future reference.

XMAX STARRY3.0 is not a medical device and is not intended to diagnose, cure, treat or prevent diseases or other conditions. If you have any health problems, consult your doctor before using the XMAX STARRY3.0.

This product should not be used by children, women who are pregnant or breast feeding, or those with life threatening illnesses without first consulting a doctor. Never use before driving or machinery.

XMAX STARRY3.0 is not intended to administer medicinal or illegal substances of any kind. Any use of this device could subject the user to fines, penalties, and/or imprisonment under the law of your jurisdiction.

THIS PRODUCT DOES NOT CONTAIN ANY PLANT MATERIAL.

16

XMAX STARRY3.0 OVERVIEW



XMAX STARRY3.0 CONTENTS



17



SPECIFICATIONS

Battery Capacity	18650 3.7V 2600mAh
Charger/Output Voltage	5.0V/1A
Charging	Micro USB charging
On/Off	Press the Power button 3 seconds
Safety Power Duration	5 minutes and 10 minutes optional
Heating Chamber	Ceramic with embedded heating element
Screen	OLED
Temperature Range	100°C-240°C (212°F-464°F)
Size	110mm*35mm*24mm(4.31in*1.37in*0.94in)

18

OPERATING GUIDE

- Remove magnet cap




- Pack moderate ground herb into the chamber




(For concentrate, please put the metal pad into insert ceramic chamber and then load wax.)

- Replace the magnet cap



19


- Hold and press the power button for 3 seconds to turn on the XMAX STARRY3.0 and it will begin to heat up at once under the default settings. The " " will keep blinking during the heat-up stage, the " " will become solid and device vibration indicates readiness. Inhale through the mouthpiece and enjoy.



20

- Setting temperature, press the "+" to increase temperature, press the "-" to decrease temperature. (XMAX STARRY3.0 will automatically remember your last setting when restart.)


The " " will become solid and device vibration indicates readiness. Inhale through the mouthpiece and enjoy till the OLED screen off, the vibration indicates off.




- Temperature switchover between Fahrenheit and Celsius. Hold the Power button and "-" button at the same time for 2 seconds.



- Timer switchover between 5 minutes and 10 minutes. Hold the Power button and "+" button at the same time for 2 seconds.



- When Charging, the OLED screen will light on. The battery icon will change to show battery charging condition. The icon gauge will be full when battery fully charged.



After using the XMAX STARRY3.0 and power adapter, allow them to cool down before storage. Store the STARRY3.0 in a dry and cool place to protect against the effects of weather and out of reach of children or unqualified persons.

22

CHARGING

- To protect and extend the battery, It is recommended your XMAX STARRY3.0 be charged with wall adapter for at least 6 hours before its first use. (External 18650 battery charger is available but not included.)

21


CLEANING/AND MAINTENANCE

To maintain the XMAX STARRY3.0, it is recommended to clean the chamber and the mouthpiece after every use.

- Clean the mouthpiece, use a cotton swab and wipe the inner part of the mouthpiece then wipe again with a damp paper towel.



- Clean the filter. Prepare a glass container filled with isopropyl alcohol. Remove the filter from magnet cap, and place it in the isopropyl alcohol.



- Clean the Ceramic heating chamber, wet a cotton swab in the alcohol. Insert into the chamber and scrub the sides and bottom with a circular motion.



23

- After soaking, remove any remaining debris using a cotton swab. Allow both pieces to dry completely before use.

NOTE:

DO NOT CLEAN THE WHOLE DEVICE WITH WATER OR SUBMERGE.

DO NOT INJECT ANY LIQUID OR OIL INTO THE CERAMIC CHAMBER.

MAKE SURE DEACTIVATE THE XMAX STARRY3.0 BY LOCKING. MAKE SURE IT HAS NOT BEEN USED FOR AT LEAST 30 MINUTES AND IS COMPLETELY COOLED OFF.

WARNING

DO NOT TOUCH THE HEATING ELEMENT IMMEDIATELY AFTER USE, PLEASE ALLOW DEVICE TO COOL DOWN.

DO NOT SUBMERGE OR CLEAN WITH WATER OR ISOPROPYLALCOHOL.

SAFETY

Prior to your first use, please read and fully understand the instructions including the safety information. We recommend that these instructions be kept for future reference.

Failure to follow warnings may result in a safety hazard including electric shock, fire, property damage, bodily injury or death.

24

AGE

You must be of legal age in your and other jurisdiction to purchase or use the XMAX STARRY3.0. For adult use only.

USE

Never use the product before reviewing the manual in its entirety. If any section or topic is unclear, prior to use, please contact customer service for clarification.

This product should not be used by children, women who are pregnant or breast feeding, or those with life threatening illnesses without first consulting a doctor. It is recommended that all users consult a doctor prior to use with your chosen herb or concentrate. Note that the XMAX STARRY3.0 is not a medical device and is not intended to diagnose, cure, treat, prevent any diseases or other medical conditions. XMAX STARRY3.0 is not intended to administer medicinal or illegal substances of any kind. Any illegal use of this device could subject the user to severe fines, penalties, and/or imprisonment under the laws of your and other local jurisdiction.

DAMAGE

Immediately discontinue use of the product if the vaporizer unit is damaged in any way including but not limited to: dents, overheating, unusually restrictive airflow, and/or electrical malfunctions. Do not attempt to repair product by disassembly of non-replaceable parts except Mouthpiece, Heating Element, Packing Tool, Removable Battery. Please contact customer service for help with any damaged unit.

25

All Batteries may explode or burst into flame if used improperly or mistreated. Do not disassemble, puncture, tamper, cut, crush, short-circuit, incinerate or expose to water, fire or high temperature above 60°C or 140°F. Never use damaged or improperly wrapped batteries with this device.

It is your responsibility to understand the dangers as well as the proper procedures for handling all batteries. Do not dispose of in trash containers nor litter the environment. Please recycle or dispose according to local safety regulations law. (Suggested to cover terminals with proper insulating tape before disposal)

WARNING

THIS PRODUCT IS NOT INTENDED FOR NICOTINE.

PRODUCT IS DESIGNED FOR LEGAL HERB USE ONLY. PRODUCT DOES NOT CONTAIN ANY HERBAL MATERIALS.

KEEP DEVICE AWAY FROM CHILDREN AND PETS.

LIMITED WARRANTY

The product is warranted for a period of one (1) year from purchase with receipt or one (1) year from date of manufacture without receipt against defects in manufacturing, workmanship, and materials. This device is designed for the use of legal concentrates only. Any use of the XMAX STARRY3.0 with illegal substances will void the warranty.

26

The warranty does not apply to damage caused by accident, abuse, misuse, natural disaster, user error, or use outside the intended use described in the manual. Use outside the intended use as described in this manual also includes any tampering with device in any way including but not limited to modification to alter functionality or modification to alter appearance.

The warranty also does not apply to cosmetic damage including but not limited to dents, scratches/chips to finish, and/ or broken plastic parts.

Normal product wear and tear is not covered under warranty. Normal performance degradation of batteries is also not covered by the warranty.


To make a warranty claim, please contact customer support at support@topgreencig.com. The original bill of sale, authenticity code, pictures or videos, and any serial numbers are required to redeem the warranty.

At the manufacturer's discretion, warranty service will be provided by repair of the product or exchange of the product and/or part with a new or functionally equivalent product/part.

CUSTOMER SUPPORT

For any question or concerns with the product, it's use or defects, please contact customer support at support@topgreencig.com. We will do our best to provide a response within two (2) business days after receipt of written notice.

www.topgreen-tech.com
© Topgreen Technology 2019



27

尺寸：60X115mm，装钉